


Product Manual

1115 - Gas Pressure Sensor



Phidgets 1115 - Product Manual For Board Revision 0 © Phidgets Inc. 2009

Contents

4 Product Features

- 4 Connections
- 4 Type of Measurement

5 Getting Started

- 5 Checking the Contents
- 5 Connecting all the pieces
- 5 Testing Using Windows 2000/XP/Vista
- 7 Testing Using Mac OS X

7 Programming a Phidget

- 7 Code Samples
- 7 Coding for your Sensor

8 Technical Information

- 8 Formulas
- 8 Other Interfacing Alternatives
- 8 Analog Input Cable Connectors
- 9 Mechanical Drawing
- 9 Device Specifications

9 Product History

9 Support

Product Features

- Measures absolute gas pressure from 20 to 250 kPa (2.9 to 36.3 psi) with a maximum error of $\pm 1.5\%$.
- Suitable for measuring vacuum or atmospheric pressure.
- Can be used as a crude barometer.

Connections

Designed to connect to a:

- 1018 PhidgetInterfaceKit 8/8/8
- 1019 PhidgetInterfaceKit 8/8/8 w/6 Port Hub
- 1070 PhidgetSBC
- 1202 PhidgetTextLCD

Type of Measurement

The sensor uses ratiometric measurement.

Checking the Contents

You should have received:


- A Gas Pressure Sensor
- A Sensor Cable

In order to test your new Phidget you will also need:

- A PhidgetInterfaceKit 8/8/8 or a PhidgetTextLCD
- A USB Cable

Connecting all the pieces

- 1. Connect the Gas Pressure Sensor to the Analog Input 6 on the PhidgetInterfaceKit 8/8/8 using the sensor cable.
- 2. Connect the PhidgetInterfaceKit to your PC using the USB cable.



Testing Using Windows 2000/XP/Vista

Downloading the Phidgets drivers

Make sure that you have the current version of the Phidget library installed on your PC. If you don't, do the following:

Go to www.phidgets.com >> Drivers

Download and run Phidget21 Installer (32-bit, or 64-bit, depending on your PC)

You should see the $mathba{m}$ icon on the right hand corner of the Task Bar.

Running Phidgets Sample Program

Double clicking on the icon loads the Phidget Control Panel; we will use this program to make sure that your new Phidget works properly. Since the sensor is connected to a 1018, the computer will see only the 1018. The sensor is providing data through the Analog input it is connected to.

The source code for the InterfaceKit-full sample program can be found under C# by clicking on www.phidgets.com >> Programming.


Double Click on the **m** icon to activate the Phidget Control Panel and make sure that the **Phidget InterfaceKit 8/8/8** is properly attached to your PC.

Phidget Control Panel		_ 🗆 🗵	
General WebService			
Library Information:			
Phidget21 - Version 2.1.6 - Built Apr 30 200 Phidget21.NET - Version 2.1.6.105	9 13:23:49		
Locally Attached Devices: (Double click to launch UI)			
Device 🔺	Serial Number	Version	
Phidget InterfaceKit 8/8/8	76667	826	
Start Phidget Control Panel with Windows?			

- Double Click on Phidget InterfaceKit 8/8/8 in the Phidget Control Panel to bring up InterfaceKit-full and check that the box labelled Attached contains the word True.
- 2. Make sure that the Ratiometric box is Ticked.
- 3. The number in the Analog In box gives you the current air pressure in the room. The value of 421 in the picture above correspond to 115.25 kilopascals.
- 4. You can adjust the input sensitivity by moving the slider pointer.
- 5. Click on the Sensors button to bring up the Advanced Sensor Form.

- 1. In the Sensor 6 box, select the 1115 -Pressure Sensor from the drop down menu.
- 2. The gas pressure measured by the sensor is shown here.
- 3. Formula used to convert the analog input SensorValue into pressure.

🔚 Advanced Sensor Form	
Sensor 0 Base Value	Sensor 1 Base Value
Value: 2	Value: 2
Sensor 2 Base Value	Sensor 3 Base Value
Value: 2	Value: 2
Sensor 4 Base Value	Sensor 5 Base Value
Value: 2	Value: 1
Sensor 6 1115 - Pressure Sensor	Sensor 7 Base Value
Value: 115.25kPa 2	Value: 0
(kPa) = (SensorValue/4) + 10	
3	



Testing Using Mac OS X

- Click on System Preferences >> Phidgets (under Other) to activate the Preference Pane
- Make sure that the Phidget InterfaceKit 8/8/8 is properly attached.
- Double Click on Phidget InterfaceKit 8/8/8 in the Phidget Preference Pane to bring up the InterfaceKit-Full example. This example will function in a similar way as the Windows version, but note that it does not include an Advanced Sensor Display.

Programming a Phidget

Phidgets' philosophy is that you do not have to be an electrical engineer in order to do projects that use devices like sensors, motors, motor controllers, and interface boards. All you need to know is how to program. We have developed a complete set of Application Programming Interfaces (API) that are supported for Windows, Mac OS X, and Linux. When it comes to languages, we support VB6, VB.NET, C#.NET, C, C++, Flash 9, Flex, Java, LabVIEW, Python, Max/MSP, and Cocoa.

Code Samples

We have written sample programs to illustrate how the APIs are used.

Due to the large number of languages and devices we support, we cannot provide examples in every language for every Phidget. Some of the examples are very minimal, and other examples will have a full-featured GUI allowing all the functionality of the device to be explored. Most developers start by modifying existing examples until they have an understanding of the architecture.

Go to www.phidgets.com >> Programming to see if there are code samples written for your device. Find the language you want to use and click on the magnifying glass besides "Code Sample". You will get a list of all the devices for which we wrote code samples in that language.

If this is your first time writing a program to control a Phidget, you should read the Getting Started Guide for the language you are planning to use.

Coding for your Sensor

Phidget analog sensors do not have their own API, but instead their output is a voltage that is converted to a digital value and accessed through the SensorValue properties and events on a PhidgetInterfaceKit. It is not possible to programmatically identify which sensor is attached to the Analog Input. Your application will need to apply any formulas from this manual to the SensorValue to translate it into usable data.

See the PhidgetInterfaceKit product manual for an overview of its API and a description of our architecture.

Technical Information

Measures absolute gas pressure from 20 to 250 kPa.

Note: If you are interested in the difference in pressure between two points (Atmospheric vs. Human lungs for example) this sensor would not be appropriate. The gas pressure sensor required for this type of application is referred to as differential.

Formulas

The Formula to translate SensorValue into Pressure is:

```
Pressure (in kilopascals) = (\text{SensorValue}/4) + 10
```

Other Interfacing Alternatives

If you want maximum accuracy, you can use the RawSensorValue property from the PhidgetInterfaceKit. To adjust a formula, substitute (SensorValue) with (RawSensorValue / 4.095)

If the sensor is being interfaced to your own Analog to Digital Converter and not a Phidget device, our formulas can be modified by replacing (SensorValue) with (Vin * 200). It is important to consider the voltage reference and input voltage range of your ADC for full accuracy and range.

Analog Input Cable Connectors


Each Analog Input uses a 3-pin, 0.100 inch pitch locking connector. Pictured here is a plug with the connections labeled. The connectors are commonly available - refer to the Table below for manufacturer part numbers.



Cable Connectors			
Manufacturer	Part Number	Description	
Molex	50-57-9403	3 Position Cable Connector	
Molex	16-02-0102	Wire Crimp Insert for Cable Connector	
Molex	70543-0002	3 Position Vertical PCB Connector	
Molex	70553-0002	3 Position Right-Angle PCB Connector (Gold)	
Molex	70553-0037	3 Position Right-Angle PCB Connector (Tin)	
Molex	15-91-2035	3 Position Right-Angle PCB Connector - Surface Mount	

Note: Most of the above components can be bought at www.digikey.com

Mechanical Drawing



Note: When printing the mechanical drawing, "**Page Scaling**" in the Print panel must be set to "**None**" to avoid re-sizing the image.

Device Specifications

Characteristic	Value	
Minimum Measurable Pressure	20 kPa	
Maximum Measurable Pressure	250 kPa	
Typical Voltage Output Range at Nominal 5.1V Supply	0.204VDC to 4.896VDC	
Device Supply Operating Range	4.74VDC to 5.46VDC	
Maximum Error over O°C to 85°C	±1.5%	
Current Consumption	5mA	
Output Impedance	1K ohms	
Pressure Port Outside Diameter Min/Max	2.8mm / 3.3mm	
Pressure Port Outside Diameter Nominal	3mm	

Product History

Date	Board Revision	Comment
August 2004	n/a	Using MPXA4250 sensor
October 2007	n/a	Using MPXA6250 sensor

Support

Call the support desk at 1.403.282.7335 8:00 AM to 5:00 PM Mountain Time (US & Canada) - GMT-07:00

or

E-mail us at: support@phidgets.com